

INSTRUCTIONS

Drying cabinet FC 20

User instructions



Select program

Change program with P-button.



Start /cancel program

Push start /stop button. Open doors to pause.

Programs

Automatic programs.

Drying stops automatically.



MEMBRANE

Fire fighting suits with membrane fabric.



WITHOUT MEMBRANE

Fire fighting suits without membrane fabric e.g. suits with wadding.



STATIONWEAR

Station and sportswear e.g. t-shirts, sweatshirts and pants.

Select drying time manually



TIMED DRYING

Set the drying time manually.



Additional functions



Fast forward to cool down phase.



Remove hangers that are not in use.